

RULES OF SAFE USE OF THE AUTO DRIVE TRACTOR

This document presents the conditions for the safe use of the AD tractor, i.e a tractor with the GOtrack Auto DRIVE system installed working without an operator on the tractor seat.

AREA.

The AD tractor cannot drive on public roads. In order to travel on public roads, an operator is required at the operator station and the AD system must be inactive.

The AD tractor may only move on properly fenced private property. Guidelines for proper fencing can be found in the "GUIDELINES FOR FENCING" section.

The area in which the AD tractor will move must be marked in accordance with the instructions contained in the "MARKING GUIDELINES" section.

USER

All users indicated by the Buyer are obliged to be trained in the operation and safety of using the AD tractor and to comply with the indicated safety rules. The User confirms that he has read the safety rules and his obligation to comply with them by signing the User Training Protocol and the Conditions of Use Protocol.

The User is responsible for the proper/safe functioning of the AD tractor.

GUIDELINES FOR FENCING

To ensure safety, the area where the AD tractor moves should be fenced. The fence should not be lower than 1 m and resist the bumper with a force not less than 100N. The fence may be made of fence wire netting, with posts spacing on average every 4 m, not less than every 5 m, or made of wooden or concrete posts, where their spacing is not should be smaller than every 1m.




Diagram 1. Graphic specification of required fence with wire mesh




Diagram 2. Graphic specification of required fence without wire mesh, just posts

MARKING GUIDELINES

In order to ensure safety, the area where the AD tractor moves should be properly marked. The markings should be visible from a distance to outsiders and placed with a frequency of not less than 1 sign per 100m and at every entrance to the area. The marking should be consistent with the graphic below:



Diagram 3. Warning sign pattern, A4 format



Diagram 4. Warning sign pattern, A3 format

A graphic design in English in a vector file may be delivered to the User in electronic form by the Seller.

It is possible to purchase ready-made warning signs in English from the manufacturer of the Auto DRIVE system.

STATEMENT

The User declares that he has read the principles of safe use of the tractor with the GOtrack Auto DRIVE system installed, is aware of the risks and obligations incumbent on him and undertakes to follow the recommendations contained in the document.

SIGNATURE

Name, Surname:

.....

Street, city, post code, country:

.....

Email:

.....

Telephone number:

.....

Signature:

.....